

262400 LOW-VOLTAGE DISTRIBUTION

1. The Design Professional should evaluate installation of surge suppression on all buildings. Suppression should be a cascaded arrangement for all buildings having a heavy usage of electronic equipment. Surge suppression shall be provided on all lighting panels with electronic ballasts.
2. Panelboards shall utilize bolt-on circuit breakers.
3. All panelboards shall receive typed circuit directories.